

# The Contemporary Black Metal Bar Stool

1



Place the seat pad with the underside facing up. Place the seat back on top.

2



Center seat pad under the ring, screw in pointed screws into outer holes.

3



Put aside the assembled seat with back.

4



Fit the two bars together to form an 'x'

5



6



Turn the swivel bracket to form a star.

7



Attach swivel bracket to the base of the barstool with the shortest screws.



# The Contemporary Black Metal Bar Stool

8



Flip over the bar stool base

9



Slide ring down inside of 4 legs

10



Line up the holes and use the longest screws to fasten.

11



Place seat pad on table with underside facing up. Place the base on top of seat pad, lining up holes on the seat pad and swivel. Fasten with the shortest screw.

12



Your Contemporary Black Metal Bar Stool is Assembled!