

The Charger Plate Crate

Note: Side B has multiple vertical guides



Side A

Base

Side B

1



Slide base down channel of side B. Ensure flat side of base faces the inside of the crate. Ensure to use a non marking rubber mallet on the base panel ONLY.

2



Repeat step 1
With 2nd side B

3



Put the crate on the table to form an upside down "U" and insert side A with handle side in first. Repeat for other side A.

The Charger Plate Crate

4



Use mallet to insert "L" bracket locks into each corner slot on top of crate.

5



Ensure the rounded edges of The "L" bracket are facing down.

6



There are 6 slots on Side B. Use mallet to insert locking pegs into each slot. Ensure the rounded side faces inwards.

7



Repeat step 6 for the other side of crate.

8



Your Charger Plate Crate is Assembled!