

The Dinner Plate Crate



Base

Side A

Side B

1



Slide base down channel of side B. Ensure flat side of base faces the inside of the crate. Ensure to use a non marking rubber mallet on the base panel ONLY. Repeat with 2nd side B panel.

2



Put the crate on the table to form an upside down "U" and insert Side A with the handle side in first.

3



Put assembled side A against table top and use the rubber mallet to ensure the base is flush with already installed side A.

The Dinner Plate Crate

4



Repeat step 2 with 2nd side A.

5



Use mallet to insert "L" bracket locks into each corner slot on top of crate.

6



Ensure the rounded edges of the "L" bracket are facing down.

7



There are 6 slots on Side B. Use mallet to insert locking pegs into each slot. Ensure the rounded side faces inwards.

8



Repeat step 7 for the other side of crate.

9



Your Large Dinner Plate Crate is Assembled!