

The Comfort Chair Seat Pad

1



Lift the seat slightly away from the seat frame and use one hand to hold the seat pad. Use the other hand to gently lift the metal tab up over the metal bar at the same time as pulling the seat up and out.

2



Repeat step 1 with the other metal tab.

3



Slide seat pad completely out.

4



Gently slide new seat pad in with one hand, while using the other hand to gently lift the metal clips over the metal bar.

5



Ensure the seat is centered.

6



Your Comfort Chair Seat Pad is Replaced!